
## Example





World wide lifting equipment

## EAGLE CLAMP CO., LTD.

HEAD OFFICE: Nakanoshima INTES Bldg. 16F, 6-2-40, Nakanoshima, Kita-ku, Osaka 530-0005, Japan Phone: +81-6-6476-8150 Fax: +81-6-6476-8155

NARA DIVISION: 1112-1, Kitatahara-cho, Ikoma, Nara 630-0142, Japan (Overseas Division) Phone: +81-743-72-0022 Fax: +81-743-72-0056

BRANCHES:

SAPPORO SENDAI KITAKANTO TOKYO CHIBA NAGOYA HOKURIKU OSAKA OKAYAMA HIROSHIMA KOKURA NAGASAKI

Distributor(s)

## Clamp for all-direction lifting

For lifting, transporting, suspending, turning over and pulling

Screw clamp, with twin shackles for flexible movement, for various applications

